













GS30-PURE II NO BURN ** PLEASE DISCARD RED VENTED CAP FROM CONCENTRATING DEVICE BEFORE USE **

Note: Always swab self-sealing port with sterile alcohol prior to accessing with a sterile syringe

<p>Step 1:</p>  <p>Draw 5mL of Citrate Anticoagulant into 30mL Syringe</p>	<p>Step 2:</p>  <p>Draw 25mL whole blood from the patient, filling the syringe to 30mL</p>	<p>Step 3:</p>  <p>Load anticoagulated whole blood into the Concentrating Device</p>	<p>Step 4:</p>  <p>Counterbalance and process the Concentrating Device at</p> <p>1 minute 4200 RPM</p>
<p>Step 5:</p>  <p>Using the 30mL syringe, aspirate the platelet plasma suspension (PPS) until RBC fills the aspirating pipe.</p> <p>(Its normal to aspirate small amounts of RBC into the syringe during this process)</p>	<p>Step 6:</p>  <p>Transfer the platelet plasma suspension (PPS) into the Concentrating Accessory</p>	<p>Step 7:</p>  <p>Counterbalance and process the Concentrating Device at</p> <p>5 minutes 4200 RPM</p>	<p>Step 8:</p>  <p>Platelet Concentrate Buffycoat</p> <p>Platelet concentrate buffycoat separates out at the bottom of the Concentrating Accessory</p>
<p>Step 9:</p>  <p>Aspirate Platelet Poor Plasma</p> <p>Leave approx. 1mL buffycoat</p> <p>Inject 3-4mL of sterile Normal Saline</p> <p>Aspirate ALL platelet poor plasma. Leave 1mL buffycoat. Then inject 3-4mL Normal Saline</p>	<p>Step 10:</p>  <p>Attach the 12mL syringe and swirl to resuspend the platelet buffycoat into the Normal Saline.</p>	<p>Step 11:</p>  <p>Tilt to immerse Aspirating Pipe into NO BURN PurePRP®</p> <p>Tilt to immerse the Aspirating Pipe into the NO BURN PurePRP®</p>	<p>Step 12:</p>  <p>NO BURN PurePRP®</p> <p>Extract the NO BURN PurePRP® into the 12mL syringe.</p>